









Pos.	Code	Description
	5332164700	RUNNER FRAME
001	5332187300	COVER
002	5332187200	COVER
003	5332203400	COVER
004	7313227791	CLOSURE
005	5332187500	SIDE LEFT
006	5913210471	KNOB
007	5532146600	TANK
008	5313220261	REAR PANEL
009	5332187400	SIDE RIGHT
011	5313228721	TRAY
012	7313220561	DOOR ASSY
013	5332142600	HOOK
014	5332145600	COVER
015	7313228241	TANK
016	5332203200	PROFILE
017	6032107700	CUP PLATE
018	5332213400	TRAY
019	5332225000	BOTTOM
020	5332266300	FLOAT
021	5332169200	MEASURING SPOON
022	7313210921	COVER
023	5532134000	TANK
024	5332194900	COVER
025	5213214941	BOARD DISPLAY
027	5332218900	PUSH BUTTON
028	5532124900	PIPETTE
031	5313217701	O-RING D=3,85
032	5132110500	MICROSWITCH
033	7332203600	COMPLETE GRINDER
034	5332144900	GASKET
035	6032105300	DIFFUSER



Pos.	Code	Description
036	5332149100	O-RING
037	7332222900	INFUSION KIT
038	5032526800	WIRING TCO
039	5332195300	KEYBOARD
040	5332142200	SUPPORT
041	6132104700	SPRING
042	5132104100	MICROSWITCH
043	7332166600	SLIDER
044	5332142400	BUSH
045	5332142300	BUSH
046	5217100200	SENSOR NTC
047	5313217751	O-RING
048	5332213000	PIN
049	5332148400	VALVE
050	6132106900	SPRING
051	5332149100	O-RING
052	5332139200	FILTER
053	7313213901	GENERATOR
054	5332195000	GLASS
055	5132110500	MICROSWITCH
056	5213213971	HALL SENSOR
057	5332170600	BELT
058	7313219691	TRANSMISSION KIT
059	5532134100	CONTROL PANEL
060	5313217701	O-RING D=3,85
061	5313216501	SUPPORT
062	7313219421	VALVE
063	5213211801	PROTECTOR
064	5132106900	PUMP
065	534848	SUPPORT
066	5232104600	SENSOR REED
067	5213214971	POWER BOARD

Pos.	Code	Description
068	5132104100	MICROSWITCH
069	6113210751	INSERT
070	6213210351	NUT
071	6213211521	BUSH
072	6213210091	CONNECTION
073	6132106100	RING
074	7332196700	HEATING Element ASSY
075	5232105000	TCO
076	5513216731	FRAME
077	5232105000	TCO
078	5213214671	FLOWMETER
079	5513213781	TUBE PTFE DI2-DE4 L=135 1BUSHE
080	536373	GASKET
081	5332196900	CONNECTION
082	5513213501	TUBE PTFE DI2-DE4 L=150 2BUSHES
083	6132101300	CLIP
084	5332239200	CONNECTOR
085	535692	O-RING
086	vt205651	FILTER
087	5513212881	TUBE PTFE DI2-DE4 L=270 2BUSHES
088	6113210021	SPRING
089	5513213501	TUBE PTFE DI2-DE4 L=150 2BUSHES
090	5332196800	CONNECTION
091	5213210181	SOLENOID VALVE
092	5513213791	TUBE PTFE DI2-DE4 L=335 1BUSHE
093	5213210171	SOLENOID VALVE
094	5932124600	FRONT PANEL
095	5332196000	O-RING
096	5532133900	COUPLING
097	5313217751	O-RING
098	5332177500	O-RING
099	5332219000	PUSH BUTTON

Pos.	Code	Description
100	9824800009	CLIP CLAMP
101	537407	CONNECTION
102	5332142600	HOOK
103	5513211371	REGULATOR
104	5213212381	BOARD
113	6132103500	SPRING
114	5332139800	LEVER
115	9812631250	SCREW
116	5332139600	STOPPER
117	5332139500	VALVE
118	6132112200	SPRING
119	5332140300	PISTON
120	5313219491	SUPPORT