









Pos.	Code	Description
	5332224100	MOTOR BELT GRINDER
	7313217261	MOTOR ASSEMBLY
	5313210401	COVER
	5332164700	RUNNER FRAME
	5332270300	EXPANSION CHAMBER LID
	5332108700	GASKET
001	5532152700	COVER
002	5532152800	COVER
003	5332266700	INSERT LOWER
004	5532152900	CLOSURE
005	5532153300	SIDE LEFT
006	5313210961	KNOB
007	5532145700	TANK
008	5332228000	REAR PANEL
009	5532153100	SIDE RIGHT
010	7313226561	CONTROL PANEL ASSEMBLY
011	5313228721	TRAY
012	7313214331	DOOR
013	5332142600	HOOK
014	5332226800	COVER
015	7332199300	TRAY
016	5513211201	PROFILE
017	7032115500	CUP PLATE
018	5332266500	TRAY
019	5332225000	BOTTOM
020	5332266600	FLOAT
021	5332226300	MEASURING SPOON
022	7313211731	COVER
023	9930000980	CARAFE ASSMBLY
024	5332266900	COVER
025	5213214831	CONTROL BOARD
026	5513214821	COUPLING CARAFE

Pos.	Code	Description
027	5332259800	TUBE
028	5513210251	PIPETTE
029	6032118300	CUP PLATE
030	5532150800	FILTER
032	5113210421	SPRING MICROSWITCH
033	7332203600	COMPLETE GRINDER
034	5332144900	GASKET
035	6032105300	DIFFUSER
036	5332149100	O-RING
037	7332222900	INFUSION KIT
038	5032526800	WIRING TCO
039	5032526900	WIRING TCO
040	5332142200	SUPPORT
041	6132104700	SPRING
042	5132104100	MICROSWITCH
043	7332166600	SLIDER
044	5332142400	BUSH
045	5332142300	BUSH
046	5217100200	SENSOR NTC
047	5313217751	O-RING
048	5332213000	PIN
049	5332148400	VALVE
050	6132106900	SPRING
051	5332149100	O-RING
052	5332139200	FILTER
053	7313213901	GENERATOR
054	5213212381	BOARD
055	5113210421	SPRING MICROSWITCH
056	5213213971	HALL SENSOR
057	5332170600	BELT
058	7332167200	TRANSMISSION KIT
059	5513216731	FRAME

Pos.	Code	Description
060	5313217701	O-RING D=3,85
061	5313216501	SUPPORT
062	7313219431	VALVE
063	5232103200	PROTECTOR
064	5132106900	PUMP
065	534848	SUPPORT
066	5232104600	SENSOR REED
067	5213214841	POWER BOARD
068	5132104100	MICROSWITCH
069	6113210751	INSERT
070	6213210351	NUT
071	6213211521	BUSH
072	7013210151	CONNECTION
073	6132106100	RING
074	7332196700	HEATING Element ASSY
075	5232105000	TCO
077	5232105000	TCO
078	5213214671	FLOWMETER
079	5513213781	TUBE PTFE DI2-DE4 L=135 1BUSHE
080	536373	GASKET
081	5332196900	CONNECTION
082	5513213501	TUBE PTFE DI2-DE4 L=150 2BUSHES
083	6132101300	CLIP
084	5332212900	CONNECTION
085	5313217691	O-RING D=4,5
086	vt205651	FILTER
087	5513213791	TUBE PTFE DI2-DE4 L=335 1BUSHE
088	6113210021	SPRING
089	5513213501	TUBE PTFE DI2-DE4 L=150 2BUSHES
090	5332196800	CONNECTION
091	5213210181	SOLENOID VALVE
092	5513213791	TUBE PTFE DI2-DE4 L=335 1BUSHE

Pos.	Code	Description
093	5213210171	SOLENOID VALVE
095	5332196000	O-RING
096	5513214821	COUPLING CARAFE
097	5313217751	O-RING
098	5332177500	O-RING
113	6132103500	SPRING
114	5332139800	LEVER
115	9812631250	SCREW
116	5332139600	STOPPER
117	5332139500	VALVE
118	6132106700	SPRING
119	5332140300	PISTON
120	5313219001	SUPPORT